

Flip Top Cover (SCPH-7000X) Installation Guide

- 

1. Turn over the console and remove those 6 screw covers and screws.
- 

2. Turn over again and remove the cover from the upper left corner.
- 

3. Starting remove from the top left corner, bottom left corner, and then whole piece.
- 

4. The PS2 should now be displayed as above.
- 

5. Unscrew the 2 tiny screws which under the cover.
- 

6. Lift the cover off. (the cover can be take out when it is half opening)
- 

7. The PS2 should now be displayed as above.
- 

8. Now you can install the flip top cover. (The cover can be install when it is half opening)
- 

9. Turn over the cover and screw back those 2 tiny screws.
- 

10. Attach the Flip Top Cover to the console carefully.
- 

11. Turn over it and replace screw covers & screws.
- 

12. Enjoy it!